

6

Fix the wall plate vertically on a suitable wall or the compressor cabinet. Isolate the compressor and look out for cables and pipes when drilling.



Slide the SEP60 on to the plate, with the venting flutes at the top.



Connect all drain points, insert tube into push fitting in the inlet (top).

- 6mm tube for metric
- $\frac{1}{4}$ " tube for imperial



Connect tube into outlet fitting and feed to drain (side). Ensure a steady fall from outlet point to drain with no kinks or tight bends.

- 10mm tube for metric
- ¾" tube for imperial

**Important Always use an automatic drain.** Set timers to short open periods of one second or less. **NEVER** use manual drains which could flood the separator, forcing partially treated or untreated condensate to be discharged.







## the SEPURA<sup>™</sup> range

## Condensate Separators to suit your requirements







e: sales@sepura-technologies.com

www.sepura-technologies.com

