# SEP 120/360/900 ST



superior technologies



## Before Starting Assembly, please check contents are as follows:

- 1 White Felt Bag Filter with black tube
- 1 Silexa Filter
- 1 Test Bottle
- 1 Cleaner Tower (120,360 or 900)
- 1 Drilled Lid
- - Metal Retaining Springs

**SEP120** = 1 x 170mm

**SEP360** = 1 x 250mm

**SEP900** = 2 x 400mm

#### Service interval kit comprising;

- moulded plastic mount + screw
- printed card
- · self-adhesive Timestrip.

#### Fitting kit containing;

- 1 Straight adaptor 15mm x 1/2" BSP
- 1 Blanking Plug large
- 1 Elbow 15mm
- 1 Assembled Porting Block
- 3 Porting Block Small Blanking Plugs
- 4 Screw 4.8x45mm and washers
- **2** Grab Taps
- 1 Blue nylon adaptor
- **1** Black Tube:

**SEP120** = 73mm

**SEP360** = 100mm

**SEP900** = 180mm

### **Service Indicator -** assembly and attachment



- Insert the boss on the reverse of the mount (c) into the pre-drilled hole in the separator lid.
- Peel backing from timestrip (a) and attach to the plastic card (b) within the dotted lines.
- Flex the card, passing the ends through the slots on the top surface of the mount.

**To activate,** press firmly on the timestrip label at the point indicated.

After a few minutes a red line will appear, to indicate 'time in service' up to 12 months

A replacement card and timestrip will be supplied with each service kit.

#### **General Installation notes**

- Please ensure a steady fall in the pipe run from the outlet point to the foul drain.
- Never discharge condensate to a storm drain or to surface water; always connect to a foul drain or sewer.
- Remember that it's the user's responsibility to check with the local authority as to the permissible discharges in their area.

### **Testing Quality**

Replace filters before outlet cloudiness exceeds the ppm limit for your region.

Test outlet quality weekly using kit provided.



Further information is available on our website below.



# SEP 120/360/900 ST



Fit the inlet block to your chosen side using the screws provided. (Extra blocks can be purchased if required.)







Insert the metal retainer(s) with bent ends facing upwards. Slide down until it touches the top of the filter bag. DO NOT compress the filter bag.



Insert the second filter bag (needle-felt bag with black inlet tube) and rest it on top of the retainers.




Screw the inlet connector (Reducing Bush) into place tightly.



Connect the filter tube to the inlet block using the fittings supplied.







lid of the unit using the pre-drilled hole. See overleaf for more detail.



Completed **SEP 120 ST SEP 360 ST SEP 900 ST** Units

For information on the correct positioning and installation of your Sepura Separator Unit please see the accompanying leaflet.











t: +44 (0)1543 379212

e: sales@sepura-technologies.com

www.sepura-technologies.com