Fix the wall plate vertically on a suitable wall or the compressor cabinet. Isolate the compressor and look out for cables and pipes when drilling.

6



Slide the SEP60 on to the plate, with the venting flutes at the top.



Connect all drain points, insert tube into push fitting in the inlet (top).

- 6mm tube for metric
- $\bullet~1\!\!4''$  tube for imperial

Anti-siphon Vent (Do NOT block)

OUTLET

Connect tube into outlet fitting and feed to drain (side). Ensure a steady fall from outlet point to drain with no kinks or tight bends.

- 10mm tube for metric
- ¾" tube for imperial

**Important Always use an automatic drain.** Set timers to short open periods of one second or less. **NEVER** use manual drains which could flood the separator, forcing partially treated or untreated condensate to be discharged.







## the SEPURA<sup>™</sup> range

## Condensate Separators to suit your requirements











## SEPURA!

t: +44 (0)1543 379212

e: sales@sepura-technologies.com

www.sepura-technologies.com