

Fix the wall plate vertically on a

suitable wall or the compressor

cabinet. Isolate the compressor and look out for cables and pipes

when drilling.

6





OUTLET

Slide the SEP60 on to the plate, with the venting flutes at the top.

Connect all drain points, insert tube into push fitting in the inlet (top).

- · 6mm tube for metric
- 1/4" tube for imperial

Connect tube into outlet fitting and feed to drain (side). Ensure a steady fall from outlet point to drain with no kinks or tight bends.

- 10mm tube for metric
- ¾" tube for imperial

Important Always use an automatic drain. Set timers to short open periods of one second or less.

NEVER use manual drains which could flood the separator, forcing partially treated or untreated condensate to be discharged.







the SEPURA[™] range

Condensate Separators to suit your requirements











SEPURA!

t: +44 (0)1543 379212

e: sales@sepura-technologies.com

www.sepura-technologies.com